

TROY PRODUCTS INSTALLATION INSTRUCTIONS  
IMPALA WINDOW BAR (FOR OEM DOOR)  
WG-IMP-WDS & WG-IMP-WPS

---

**WINDOW BARS**

Begin the window bar installation by first removing (and discarding) the triangular OEM plastic part as shown below.



**OEM Part Still in Place**



**OEM Part Removed**

Place window bar frame on top of OEM door panel.

Once you have the window frame centered in place, drill through eight (8) pilot holes pre-punched in the window frame and secure in place with hardware provided by TROY.

When finished, your window installation should look like this.

If you have any questions regarding these installation instructions, please call **Customer Service at (800) 700-8769.**



**Photo shows Troy door panel but window guard works also with OEM door.**